



VESPER DIAGRAMS



EXPOSED






RECESSED



VESPER DIAGRAMS

STRAIGHT BRACKET

DIMENSIONS IN INCHES (US)



vesper backplates shown over US j-boxes



Obsolete

TAKING CARE OF YOUR VESPER WALL LIGHTS (EXPOSED LIGHTBULBS) US

CLEANING

The surface should only be cleaned lightly with a soft cloth or duster. A barely damp soft cloth can be used for anything trickier to remove, but please resist any urge to rub hard. Once wiped clean, the surface may be lightly waxed with a natural beeswax and polished with a soft lint-free cloth. This helps to nourish and protect the surface and will develop a warm and natural patina over time. No abrasive cloth or cleaning agent should ever be used to clean the brass.

BULBS AND LAMP FITTINGS

Bulbs should only be changed when the lamp fitting is switched off. Bulbs should be firmly screwed into the fitting before switching back on, or it's possible that shorting may occur. All our lighting is continuity tested and PAT tested at the time of making.

We recommend using E26 3.15" diameter 75W dimmable LED globe bulbs with a colour temperature of 4000K (different colour temperatures are available).

FIXING YOUR VESPER WALL LIGHT TO THE WALL




Each light has been supplied with colour matched screws. To fix your Vesper wall light in position, please ensure you consult with your electrician and use the correct secondary fixings for your wall type.

11270 Washington Blvd. Culver City, CA, 90230
(310) 399-0024
www.obsoleteinc.com | what@obsoleteinc.com



VESPER DIAGRAMS

STRAIGHT BRACKET

DIMENSIONS IN INCHES (US)



vesper backplates shown over US j-boxes



Obsolete

TAKING CARE OF YOUR VESPER WALL LIGHTS (RECESSED LIGHTBULBS) US

CLEANING

The surface should only be cleaned lightly with a soft cloth or duster. A barely damp soft cloth can be used for anything trickier to remove, but please resist any urge to rub hard. Once wiped clean, the surface may be lightly waxed with a natural beeswax and polished with a soft lint-free cloth. This helps to nourish and protect the surface and will develop a warm and natural patina over time. No abrasive cloth or cleaning agent should ever be used to clean the brass.

BULBS AND LAMP FITTINGS

Bulbs should only be changed when the lamp fitting is switched off. Bulbs should be firmly screwed into the fitting before switching back on, or it's possible that shorting may occur. All our lighting is continuity tested and PAT tested at the time of making.

We recommend using E26 B13 7W (60W equivalent) dimmable LED bulbs with a colour temperature of 2700K (different colour temperatures are available).

FIXING YOUR VESPER WALL LIGHT TO THE WALL

Each light has been supplied with colour matched screws. To fix your Vesper wall light in position, please ensure you consult with your electrician and use the correct secondary fixings for your wall type.

11270 Washington Blvd. Culver City, CA, 90230

(310) 399-0024

www.obsoleteinc.com | what@obsoleteinc.com

